

Water Butt Linking Kit

Fitting Instructions

The water butts to be connected should be on a level surface and no more than 39cms apart.

The water butts can either be connected at the top or the bottom. If connected at the bottom the 2 water butts will fill at the same rate. If connected at the top the first water butt will fill then run over into the second.

1. Drill a 25mm hole approx. 25cms from the top or the bottom into opposite sides of the water butts to be connected. Before drilling make sure both butts are facing forwards with the taps at the front.

WARNING: Do not use an electric drill if there is any water in the water butts.

2. Fit the washer to the connector and screw tight into the water butt using the backing nut on the inside.
3. Join the water butts together with the supplied hose.

